DAB-DG200AM

QUICK START GUIDE



For further product information and instruction please visit

www.laserco.net

DAB-DG200AM QUICK START GUIDE

EVERYDAY FEATURES

TURNING THE UNIT ON

(1) Extend the antenna and press the **ON/OFF** button. (2) The unit will then conduct a full auto-search scan and store all DAB/DAB+ Radio stations. The auto search may take up to 1- 2 minutes to complete. (3) The unit is then ready to use.

1)

2)



3)



MANUAL STATION SCANNING

To manually change frequency, press ▼ or ▲ to change in 0.05MHz steps. To start auto-scanning, press and hold the **SCAN** button.

1)

CHOOSING A STATION

When the auto searching is complete, you can change stations by pressing ▼or ▲.

1)

USING THE DISPLAY BUTTON

To view further station information, just press the **DISPLAY** button each time to show 1) Radio station name, 2) Frequency, 3) Signal transmission rate and mode, 4) Signal strength, 5)Time, 6) Scrolling station data, and 7) Radio Program Type

1)



DAB-DG200AM QUICK START GUIDE

SWITCHING BETWEEN AM, FM AND DAB+
While enjoying a DAB/DAB+ program, you can simply press **DAB/FM/AM** to change Modes

1)

PRE-SETTING FAVOURITE CHANNES
This radio can store 10 DAB/DAB+, 10 FM station and 10 AM station presets. To store the current station (1) press and hold the **PRESET** button. Then press ▼or ▲ and **SELECT** your preferred channel number. (2) A confirmation screen will then be shown

1)



2)

SELECTING A PRESET STATION
To recall your list, press PRESET.
Press ▼or ▲ to review and press SELECT to confirm.



SETTING LANGUAGE/FACTORY RESET
***Note**: Changing language is also accompanied with a factory reset, which means all personal settings will be deleted.*

(1) Press **MENU** repeatedly until "**Language"** is shown. Press **SELECT** to confirm. Press ▼or ▲ to select from the list. (2) Press **SELECT** to confirm your preference. The system will then reset and restart.

1)



2)



DAB-DG200AM QUICK START GUIDE

What's in the box: 1 DAB+ Radio, 1 Power Adaptor, 1 Quick Start Guide







Please use 6 X "C" (R14/UM2) Size batteries (Not included). Type and quality of battery used in the product may affect the audio quality.

For further product information and instruction please visit our product web page www.laserco.net